#PKSPPXX PSI Woodworking Products

Steam Punk Bolt Action Pen Kit

Kit Features:


- Easy to turn with straight tubes
- Minimum parts easy to assemble
- Available in multiple finishes
- Decorative Hand Made Components
- Uses Parker® Style Refill
- Overall Length: 6" Long

Required Accessories:

- 7mm Pen Mandrel
- Drill Bit: 3/8" # BG039
- Bushing set(2 pc): # PSI 264
- Barrel Trimming set: Squaring Jig or Barrel Trimmer
- Live Tailstock Center or Mandrel Saver tailstock Center
- 2 Part Epoxy or (Cyanoacrylate) CA Glue
- Pen Blank: Minimum Size: 3/4" x 2-1/4"




DIAGRAM A / PARTS LAYOUT



Preparing the Blank:

- Cut 1 blank to the length of the tube and add 1/16" for squaring off.
- Drill a 3/8" hole lengthwise through the blank.
- Spread glue over the tube, insert the blank with a twisting motion to spread the glue evenly inside.
- Center the tube lengthwise inside the blank.
- When the glue is dry, square the ends of the blanks. Use a 3/8" barrel trimmer shaft, or a universal pen blank squaring jig with a power disc sander. Take the excess material down flush with the ends of the brass tube. (do not trim beyond the length of the tube since this may interfere with operation of the mechanism and assembly). Use a barrel trimmer to clean the inside of the tube.



Turning the Blank

- Mount the bushings and blanks according to diagram B.
- Thread on the knurled nut and hand tighten to hold all components in place.
- Slide the tailstock up snugly against the mandrel shaft inserting the live center point into the mandrel dimple, lock in place.
- Hand tighten the quill adjustment to firm up the mandrel. (DO NOT overtighten, it could damage the mandrel.)
- Using sharp tools, turn the blank down close to the bushing diameter. Turn the barrel (straight or to a profile of your choice)
- Sand the blank down to be flush with the bushings gradually increasing the sandpaper grits.
- Finish the barrel with your choice of polish. Allow sufficient time for the polish to cure. Refer to polish instructions.

Assembly

- Layout parts according to diagram A.
- Press the front end assembly into either end of the barrel.
- Press the back end assembly into the other end of the barrel.
- Unscrew the tip of the assembly.
- Affix the spring over the refill, insert the refill into the opening at the tip, drop in.
- Screw the tip back in place.
- The pen operates by sliding the bolt forward then back when not in use.

Diagram C / Bushings # PSI 264

